

Tandem Gearcase with and without Sensor

70301093	Tandem Gearcase with Sensor (Left Hand)
70301033	Tandem Gearcase without Sensor

1	70301505	1	Key and Plug Kit (Key and 3 Plugs)
2	70311062	1	Washer
3	70313077	2	Pinion Gear
4	70313084	1	Drive Gear
5	70315052	1	Tandem Inboard Housing
6	70315090	1	Tandem Outboard Housing with Sensor (LH)
6	70315082	1	Tandem Outboard Housing without Sensor
7	70601151	4	Bearing (Large 50 x 80 x 16mm)
8	70601173	2	Small Output Bearing
9	70601350	1	Oil Seal
10	70611952	1	Tandem Gearcase Gasket
11	70617006	10	Lock Washer
12	70620041	10	Capscrew
13	70601360	1	Seal for Sensor
14		1	Plug (Purchase in Key and Plug Kit)
15		1	Center Fill Plug (Purchase in Key Kit)

